+ Step 4 - Turning ON the Device

Note: The device should only be turned on when you are ready to go to sleep.



- 4a. Press firmly on the Power button until the display lights up. Next screen "Please wait Testing..." After a few seconds "GOOD NIGHT!!!" ✓ message will appear. The display will turn OFF after a short period.
- **4b.** In the case there is a problem, "TEST ABORTED" ★ will appear, call help desk 1-888-748-2627

You are now ready to go to sleep.

4c. In the case your finger is not inside the probe, an error appears instructing you to insert the finger. Wait till the device turns off, insert finger and try again.

• Step 5 - During the night

- Anytime you press on the button, the display will light up for a minute.
- If you need to get up during the night, do not remove the device or sensors.
- Do not press any buttons if you need to get up during the night.
- If using the bathroom, do not get the WatchPAT[™] 300 wet.
- The WatchPAT™ 300 should not cause any discomfort or pain. Should you encounter unbearable discomfort, remove the device and call the help desk.

+ Step 6 - Next Morning

When you wake up:

- **6a.** Device will turn off automatically. There is no OFF button.
- **6b.** Remove the finger probe and the RESBP sensor
- 6c. Take off from your wrist.
- **6d.** Insert all parts back into the carrying case.

Important Notes

- Do not attempt to connect or disconnect any part of the unit.
- Do not try to introduce any foreign object into the unit.
- Do not try to connect the WatchPAT[™] 300 to an electrical supply or other device, machine or computer.
- Do not, under any circumstances, attempt to fix a problem by yourself.

Questions?

Call our Help Desk Number 1-888-748-2627

itamar

medical | Health Being Made Simple www.itamar-medical.com | infousa@itamar-medical.com

Worlwide:

🖬 Itamar Medical Ltd.

9 Halamish Street, PO 3579 Caesarea 3088900, Israel Tel + 972 4 617 7000 Fax + 972 4 627 5598

USA:

Itamar Medical Inc.

3290 Cumberland Club Drive, Suite 100 Atlanta, Georgia 30339, USA Tel 1 888 748 2627 **ECREP** Arazy Group GmbH The Squaire 12, Am Flughafen,

The Squaire 12, Am Flughafen, 60549 Frankfurt am Main, Germany

Caution: US federal law restricts this device to sale by or on the order of a licensed healthcare practitioner.

pyright © 2022 Itamar Medical Ltd. WatchPAT and PAT are trademarks or registered trademarks of Itamar edical Ltd., a subsidiary of ZOLL Medical Corporation, in the United States and/or other countries.

Step by Step Guide

WatchPAT[™] 300 Home Sleep Test



For an instructional video go to: www.watchpat-howtouse.com



WatchPAT 300 - Step by Step Guide

This guide is to be used after your practitioner has showed you how to use the WatchPAT[™] 300 device.



A - Power Button **B** - Respiratory Effort Snoring and Body Position sensor (RESBP) **C** - Finger Probe

Before applying the WatchPAT[™] 300:

- It is recommended to apply the WatchPAT[™] 300 device to your non-dominant hand.
- Probe can be worn on any finger, except the thumb. If you have large fingers, the pinky is recommended.
- Before use, remove tight clothes, rings, watches and other jewelry.
- Remove nail polish and artificial nails from the test finger and make sure the fingernail is cut short.

Note: Once you have turned on the WatchPAT[™] 300 device, it cannot be turned off.

Apply the device and turn it on only when you are ready to sleep.

Note: Adult supervision may be required to apply the device. Note: Images in the demonstrated guide are for the left hand; similar process can be applied for the right hand.



The carrying case contains:

- This reference quide
- Device with Finger Probe
- Respiratory Effort Snoring and Body Position sensor (RESBP)

Help Desk Number 1-888-748-2627

Step 1 - Applying the Respiratory Effort Snoring and Body Position sensor (RESBP)



- **1a.** For men: trim thick chest hair, if needed.
- **1b.** Take the RESBP Sensor through the sleeve of your night shirt up to the neck opening.



1d. Stick the sensor to the center of your upper chest bone, just below the front of neck. Make sure the image on the RESBP sensor is upward facing.



1c. Peel the white paper from the back of the sensor.

+ Step 2 - Applying the WatchPAT[™] 300 Device




2a. Strap the device to your non-dominant hand. **2b.** Close wrist strap (not too tightly).

Step 3 - Applying the Finger Probe



- **3a.** Probe can be worn on any finger, except the thumb. If you have large fingers, the pinky is recommended
- **3b.** Insert the finger into the probe until vou feel the end. The sticker marked TOP should be on the top of your finger (Above the nail).



probe against a hard



- - **1e.** Secure the RESBP sensor with additional medical tape.